


# SII software school: Lesson 3



your SII analysis

T. Hassan on behalf of  
the magic\_spysii dev team



European Research Council

Established by the European Commission

**Ciemat**

Centro de Investigaciones  
Energéticas, Medioambientales  
y Tecnológicas

# IACt-SII: Lesson I & II wrap up

- Downloading/synchronizing data, and “reducing” it should be a piece of cake now
- Visualizing binary data should also be easy, and the user should understand the meaning of most parameters plotted
- Analyzers should have, more or less, an idea of the information that each level of analysis contains
- Analyzers are able to perform the analysis of any star they like

**Although most likely, you don't know yet what you are doing!**





**And that is ok!**

# IACT-SII: Lesson III

- Review basic concepts of interferometry (you will start needing them now)
- Understand the meaning of zero-baseline correlation
  - How to generate a “ZBC calibration file”
  - How to use it
- Side step: first steps towards MAGIC-LST analysis:
  - Which runs have MAGIC+LST1 data?
  - How do I download LST DC reports?


# Gentle introduction to interferometry

Amazing angular resolution, but hard to understand



# Principle of interferometry

- A technique to reach unprecedented angular resolution, by using several separated telescopes “working as one”



But how do they work?



# Introduction to SII: The very basics



Glasses improve our  
angular resolution



# Introduction to SII: The very basics




What would happen if these glasses allowed us to see the **Fourier space**?




# Introduction to SII: The very basics



We would (quite literally) look  
at a **complex** universe




**Intensity**




**Phase**




# Introduction to SII: The very basics




# Introduction to SII: The very basics



2D FFT<sup>-1</sup>



Phase is important!



?


Intensity

Phase


# Introduction to SII: The very basics



An interferometer is something  
very similar to these  
“Fourier” glasses



**Intensity (u,v)**




**Phase**




# Introduction to SII: The very basics



More telescopes  $\rightarrow$  more information  
from the Fourier space  $\rightarrow$  more spacial  
information  $\rightarrow$  better imaging



**Intensity ( $\mu\text{V}$ )**



**Phase**



# SII analysis theory

- Van Cittert-Zernike Theorem:


$$g^{(1)}(u, v, 0) = \iint I(l, m) e^{-2\pi i(lu + mv)} dl dm$$

# SII analysis the

- Van Cittert-Zernike Theorem

$$g^{(1)}(u, v, 0) = \iint I(l, m) e^{-2\pi i(lu + mv)} dl dm$$

Sky model




# SII analysis theory


- Van Cittert-Zernike Theorem:

$$g^{(1)}(u, v, 0) = \iint I(l, m) e^{-2\pi i(lu + mv)} dl dm$$



Sky model



$$g^{(2)}(u, v, t) = 1 + |g^{(1)}(u, v, t)|^2$$







# $V^2$ vs baseline: radially symmetric UV models






# SII analysis theory




# SII analysis theory

- These models generally have 2 free parameters:



# SII analysis theory: zero-baseline correlation

- These models generally have 2 free parameters:




# SII analysis theory: zero-baseline correlation

- These models generally have 2 free parameters:
  - 1) Diameter of the measured star
  - 2) Normalization parameter (zero-baseline correlation)
- Zero-baseline correlation is **fixed by your hardware setup**, and mainly depends on optical and electronic bandwidth
  - In our case, as we use DC reports to normalize the correlation, pixel gains also affect ZBC




# SII analysis theory: zero-baseline correlation

- During the performance paper work, all sources were consistent with **a single ZBC**:




# SII analysis theory: zero-baseline correlation


- During the performance paper work, all sources were consistent with **a single ZBC**:



# ZBC: Adding a ZBC to an analysis




# ZBC: Adding a ZBC to an analysis





# ZBC: Create your own ZBC calibration file

- `magic_spysii` allows to extract all information related to the ZBC from an analysis, and use it over other analyses
- The way to do this is trivial: once you have an analysis with good ZBC...



`> extract_zbc_file [ANALYSIS FILE].pkl`

This executable will generate a file caled:  
`zbc_[ANALYSIS FILE].pkl`


# ZBC: Use your ZBC calibration file

- Obviously you should not use the extracted ZBC on the same source, but you can use it on any other! How?


> sii\_production config\_file.yml

```
...  
# The following are the parameters used at the "analysis" level:  
analysis:  
  # In case you want to add a ZBC measurement to the analysis, set the  
  # [path]/[filename] of the pkl file here. If not,  
  # set as None. This is considered the calibration of the system, and impacts  
  # strongly on the resulting diameter.  
  add_zbc: [PATH_TO_ZBC_FILE]/zbc_Adhara_M1-251_M2-251.pkl  
...
```


# ZBC: Adding a ZBC to an analysis



# ZBC: Adding a ZBC to an analysis



# ZBC: Adding a ZBC to an analysis



For many sources, the effect of adding a ZBC value has dramatic impact

By “fixing” one parameter, correlation data is used to constrain almost exclusively the stellar diameter measurement

# ZBC: Things to remember

- As stated before, ZBC is fixed by **the hardware setup**.

What does this mean?

- Measuring the correlation between different pixels (e.g. 251-251 vs 260-260) may lead to small differences in ZBC → better not to combine 251 and 260 pixels
- Differences between MAGIC pixels may be small, but MAGIC vs LST pixels will be **very different** → definitely never combine
- PMTs degrade with time, so we expect ZBC to evolve over month/year timescales

# ZBC: Things to remember

- As stated before, ZBC is fixed by **the hardware setup**.

What does this mean?


- Measuring the correlation between different pixels (e.g. 251-251 vs 260-260) may lead to small differences in ZBC → better not to combine 251 and 260 pixels
- Differences between MAGIC pixels may be small, but MAGIC vs LST pixels will be **very different** → definitely never combine
- PMTs degrade with time, so we expect ZBC to evolve over month/year timescales



# MAGIC-SII → MAGIC-LST1-SII



Remember we have 3  
telescopes now!!

(and soon more will  
be coming)



# MAGIC-SII → MAGIC-LST1-SII

- During MAGIC+LST1 observations we get 3 simultaneous correlations at the same time:



# IACI-SII: Lesson III wrap up

- It is trivial to extract ZBC measurements from analysis files, and use these calibration ZBC files into other analyses
- Different ZBCs are expected from different pixels, so it is advised to **never combine different pixel combinations into a single analysis**
  - Each different pixel pair should be analyzed differently
  - ZBC may not be perfectly stable: if you analyze data over years, **careful!**
- MAGIC+LST1 data

# MAGIC+LST1: DISCLAIMER

- **CAREFUL!**

- MAGIC+LST1 analysis is very recent, and still needs to be polished
- Time-delay correction is “more or less” correct, but definitely needs to be improved (correlation signals won’t be nicely located at 0 yet)
- Don’t trust these results yet. They did not undergo the long validation process of MAGIC-only data
- Help to improve this analysis would be much appreciated!

# MAGIC+LST1: First steps

- The same way as with standard MAGIC data, the first step is to download data and DC reports
  - As soon as LST1 was connected to the correlator, we added the “LST1” tag in the raw files, but knowing which runs have LST1 pointing to a star **is not trivial**
  - Simplest method: Just check a file, that contains a list of all MAGIC+LST1 runs  
**`magic_spysii/data/joint_magic-lst1_run_list.txt`**

# MAGIC+LST1: First steps

- Easy to check which nights contain MAGIC+LST1 data:

```
joint_magic-lst1_run_list.txt x
856 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_del-Per_10002_20002_20240915T004358
857 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T230329
858 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T230835
859 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T231341
860 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T231846
861 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T232351
862 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T232857
863 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T233403
864 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T233908
865 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T234414
866 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T234919
867 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T235425
868 2024_09_15, Spectrum_XCorr_acc-6C4A-LST1-joint_500MSa_Buff_500hm_200mV_5min_gam-Peg_10002_20002_20240914T235930
869
```

# MAGIC+LST1: First steps

- The same way as with standard MAGIC data, the first step is to download data and DC reports
  - As soon as LST1 was connected to the correlator, we added the “LST1” tag in the raw files, but knowing which runs have LST1 pointing to a star **is not trivial**
  - Simplest method: Just check a file, that contains a list of all MAGIC+LST1 runs  
**`magic_spysii/data/joint_magic-lst1_run_list.txt`**
  - Once you identify the nights you want to analyze, you need to download (again, **manually!**) LST1 DC reports



# MAGIC+LST1: First steps

- As with MAGIC DC reports, they need to be contained within each observing night
- The location of the reports is, from any machine with access to the fefs: **/fefs/onsite/monitoring/cameraLST1/clusco/reports**
- So, in order to download reports from one night, you may:

```
# For example, on night 2024_09_16, we make sure we have all reports from
the 15th and 16th:
> scp tcs01:/fefs/onsite/monitoring/cameraLST1/clusco/reports/2024/monitor-
240915*.txt $MAGICSIIDATA/2024_09_16/
> scp tcs01:/fefs/onsite/monitoring/cameraLST1/clusco/reports/2024/monitor-
240916*.txt $MAGICSIIDATA/2024_09_16/
```

# MAGIC+LST1: First MAGIC+LST1 analysis


- Once you have both MAGIC and LST1 DC reports, you have everything you need to start analyzing M1-LST1 and M2-LST1 correlation channels
  - In addition to M1-M2 productions, also launch the 2 additional productions (the same way, with `sii_production`)
  - Note the baseline coverage of these new correlation pairs may be very limited, and not enough to evaluate ZBC correlation properly
  - As time-delay correction is not yet perfect, correlation signals may be “far” from 0 (up to 8/9 ns). This means you may need to modify the default values within the config file:  
`peak_fitting_parameters` → `time_delay_bounds`

# IACT-SII: Lesson III – Proposed exercises

- Download more nights from Adhara (“chronologically”), ensuring you increase its baseline coverage
  - This should significantly improve ZBC determination
- Extract it's ZBC using the executable
- Use the new ZBC calibration file to analyze another source. Also try to analyze the source without the ZBC. See the difference!
- Identify nights of MAGIC+LST1 data, and download some DC reports from the night. Pick a source (with MAGIC+LST1 data), and perform 3 analyses, one from each correlation pair




# Interferometry DAQ






# Interferometry DAQ: Now



# Interferometry DAQ: Now



- Current DAQ computes:
  - Cross-correlation between each channel pair (via FFTs)
  - Auto-correlation of each channel
  - Certain useful parameters (mean and std dev of each channel)
- Current DAQ “accumulates” these, and writes the average correlation/mean/std dev every 500 cycles

# ZBC: The constant of our system

- From HB&T, we know that the expected correlation:

$$\overline{c(d)} = \langle \Delta i_1(t) \Delta i_2(t) \rangle = e^2 A^2 \alpha^2 n^2 |\gamma_d(0)|^2 \Delta \nu \Delta f \quad (4.28)$$

- After dividing by the flux, the remaining correlation should be:

$$\frac{\overline{c(d)}}{\text{flux}} \propto \frac{|\gamma_d(0)|^2}{\Delta \nu \Delta f}$$

- But as with our setup, our “flux” is the DCs (different gain than the correlation):

$$\frac{\overline{c(d)}}{\sqrt{DC^1 DC^2}} \propto \frac{|\gamma_d(0)|^2}{\sqrt{G_{DC}^1 G_{DC}^2} \Delta \nu \Delta f}$$

Any time evolution in the DC gain will be a **systematic**